

Tabulka vytyčovacích bodů

Číslo bodu	Souřadnice X [m]	Souřadnice Y [m]
1	-806636,48	-991144,30
2	-806636,85	-991144,91
3	-806637,19	-991145,53
4	-806638,74	-991147,12
5	-806640,89	-991147,65
6	-806648,72	-991147,32
7	-806651,31	-991147,42
8	-806655,36	-991148,60
9	-806660,62	-991152,83
10	-806662,09	-991154,50
11	-806663,71	-991156,02
12	-806665,00	-991154,49
13	-806663,54	-991153,13
14	-806662,22	-991151,63
15	-806660,44	-991149,65
16	-806658,19	-991147,88
17	-806655,56	-991146,50
18	-806652,75	-991145,64
19	-806648,63	-991145,32
20	-806640,81	-991145,65
21	-806639,71	-991145,38
22	-806638,96	-991144,59
23	-806638,58	-991143,91
24	-806638,17	-991143,23
25	-806658,83	-991151,00
26	-806658,05	-991150,34
28	-806622,22	-991121,56
29	-806621,62	-991120,76
30	-806620,89	-991120,08
31	-806620,06	-991119,52
32	-806619,16	-991119,10
33	-806618,19	-991118,85
34	-806617,20	-991118,75
35	-806616,20	-991118,82
36	-806614,80	-991119,22
37	-806616,57	-991113,26
38	-806617,38	-991113,85
39	-806618,17	-991114,46
40	-806618,94	-991115,10
41	-806619,69	-991115,77
42	-806620,21	-991116,26
43	-806621,11	-991117,17
44	-806621,79	-991117,90
45	-806622,44	-991118,66
46	-806623,07	-991119,44
47	-806623,67	-991120,24

48	-806624,24	-991121,06
49	-806624,79	-991121,90
50	-806630,05	-991130,14
51	-806631,12	-991131,84
55	-806644,13	-991141,44
70	-806639,76	-991144,24
71	-806645,51	-991141,20
72	-806646,07	-991142,26
73	-806648,72	-991140,86
74	-806648,16	-991139,80
75	-806653,91	-991136,77
76	-806638,97	-991108,47
77	-806633,22	-991111,50
78	-806632,66	-991110,44
79	-806630,01	-991111,84
80	-806630,57	-991112,90
81	-806624,82	-991115,94
82	-806631,75	-991129,24
83	-806632,68	-991131,01
85	-806645,26	-991141,99
86	-806645,82	-991143,05
87	-806649,50	-991141,11
88	-806648,94	-991140,04
89	-806654,69	-991137,01
90	-806639,21	-991107,69
91	-806633,46	-991110,72
92	-806632,90	-991109,66
93	-806629,22	-991111,60
94	-806629,78	-991112,66
95	-806624,03	-991115,70
96	-806631,27	-991129,40