



Legena

 Rozvaděče	 20.1	 36.4	 50.1
Úseky	 21.1	 36.5	 50.2
 1.1	 22.1	 37.1	 51.1
 1.2	 23.1	 38.1	 51.2
 1.3	 24.1	 39.1	 52.1
 1.4	 25.1	 4.1	 53.1
 1.5	 26.1	 4.2	 53.2
 1.6	 27.1	 4.3	 53.3
 1.7	 27.2	 40.1	 54.1
 1.8	 28.1	 41.1	 55.1
 1.9	 29.1	 41.2	 56.1
 10.1	 3.1	 42.1	 56.2
 11.1	 3.2	 42.2	 57.1
 12.1	 30.1	 43.1	 58.1
 13.1	 31.1	 44.1	 59.1
 14.1	 32.1	 44.2	 59.2
 15.1	 33.1	 45.1	 6.1
 16.1	 34.1	 46.1	 7.1
 17.1	 35.1	 46.2	 8.1
 18.1	 35.2	 47.1	 9.1
 19.1	 36.1	 48.1	 Přechody
 2.1	 36.2	 49.1	
 2.2	 36.3	 5.1	





39.24
39.23
39.22
39.17
39.18
39.12
39.13

RVO 98

RVO 66


RVO 77


RVO 65

RVO 62

RVO 63

RVO 64





RVO 99

RVO 84

RVO 46

RVO 48

84.39
84.37
84.38
84.35
84.36

46.17
46.16
46.15
46.14
46.13
46.11
46.12
46.9
46.10
46.8

48.62
48.64
48.54
48.55
48.61
48.65
48.60
48.67
48.59
48.70
48.2
48.3
48.4
48.5
48.7
48.6
48.10
48.12
48.11
48.9

